



## Programming Manual

UDP3000 SERIES DC Power Supplies

# Instruction List

1. \*IDN?
2. \*SAV
3. \*RCL
4. INSTrument {CH1|CH2|CH3}
5. INSTrument ?
6. MEASure:CURRent?
7. MEASure:VOLTage?
8. MEASure:POWER?
9. [SOURce:]CURRent <current>
10. [SOURce:]CURRent ?
11. [SOURce:]VOLTage <volt>
12. [SOURce:] VOLTage?
13. OUTPut
14. OUTPut:TRACk
- 15.OVP:STATus
- 16.OCP:STATus
- 17.OVP:SETting
- 18.OCP:SETting
- 19.OVP:VALUE?
- 20.OCP:VALUE?
- 21.Recall:STAT?
22. SYSTem:ERRor?
23. SYSTem:VERSion?
24. SYSTem: STATus?

## 1. \*IDN?

### Syntax

\*IDN? <name>

### Functional Description

Query the instrument information of manufacturer name, product model, product serial number and software version.

### Return Format

The query returns <manufacturer>, < product model>, <serial number>, < software version>.

## 2. \*SAV

### Syntax

\*SAV <name>

### Functional Description

Save the current setting with the specified name into nonvolatile memory.

#### Example

```
*SAV 1
```

Save the current setting with the specified name "1" into nonvolatile memory.

## 3. \*RCL

### Syntax

```
*RCL <name>
```

### Functional Description

Recall the saved instrument status.

#### Example

```
*RCL 1
```

Recall the system "status 1" from nonvolatile memory.

## 4. INSTRument

### Syntax

```
INSTRument < channel >
```

```
< Channel > := { CH1 | CH2 | CH3 }
```

### Functional Description

Select the channel that need to be operated.

#### Example

```
INSTRument CH1
```

## 5. INSTRument?

### Syntax

```
INSTRument?
```

### Functional Description

Query the currently operating channel.

#### Example

INSTRument? The query returns CH1.

## 6. MEASure:CURRent?

### Syntax

MEASure:CURRent? < channel >  
< Channel >: = { CH1 | CH2 | CH3 }

### Functional Description

Query the measured current value on the output terminal of the specified channel. If no channel is specified, it then query the currently selected channel.

### Example

MEASure:CURRent? CH1    The query returns 3.000.

## 7. MEASure:VOLTage?

### Syntax

MEASure:VOLTage? < channel >  
< Channel >: = { CH1 | CH2 | CH3 }

### Functional Description

Query the measured voltage value on the output terminal of the specified channel. If no channel is specified, it then query the currently selected channel.

### Example

MEASure:VOLTage? CH1    The query returns 30.000.

## 8. MEASure:POWER?

### Syntax

MEASure:POWER? < channel >  
< Channel >: = { CH1 | CH2 }

### Functional Description

Query the measured power value on the output terminal of the specified channel. If no channel is specified, it then query the currently selected channel.

### Example

MEASure:POWER? CH1    The query returns 90.000.

## 9. [SOURce:]CURRent <Current>

### Syntax

< Channel >: [SOURce:]CURRent < current value >

< Channel > := { CH1 | CH2 }

### Functional Description

Set the current value for the currently specified channel.

### Example

CH1:CURRent    The query returns 0.5.

## 10. [SOURce:]CURRent?

### Syntax

< Channel >: CURRent?

< Channel >: { CH1 | CH2 }

### Functional Description

Query the current value of the currently specified channel.

### Example

CH1:CURRent?    The query returns 0.5.

## 11. [SOURce:]VOLTage <volt>

### Syntax

< Channel >: VOLTage < voltage value >

< Channel >: := { CH1 | CH2 }

### Functional Description

Set the voltage value for the currently specified channel.

### Example

CH1:VOLTage 25

## 12. [SOURce:] VOLTage?

### Syntax

< Channel >: VOLTage?

< Channel >: := { CH1 | CH2 }

### Functional Description

Query the voltage value of the currently specified channel.

### Example

CH1:VOLTage?    The query returns 25.

### 13. OUTPut

#### Syntax

OUTPut, < status >  
<Status> := { ON | OFF }

#### Functional Description

Turn on/off the specified channel.

#### Example

OUTPut ON

### 14. OUTPut:TRACk

#### Syntax

OUTPut:TRACk <NR1>  
<NR1> = { 0 | 1 | 2, it respectively represents independent, serial connection and parallel connection. }

#### Functional Description

Select the operating mode.

#### Example

OUTPut:TRACk 0

### 15. OVP:STATUs

#### Syntax

OVP:STATUs, < status >  
< Status > := { ON | OFF }

#### Functional Description

Turn on/off overvoltage protection.

#### Example

OVP:STATUs ON

### 16. OCP:STATUs

#### Syntax

OCP:STATUs < status >  
< Status > := { ON | OFF }

#### Functional Description

Turn on/off overcurrent protection.

**Example**

OCP:STATus ON

**17. OVP:SETting****Syntax**

OVP:SETting < channel >,< voltage value >  
< Channel > := { CH1 | CH2 }

**Functional Description**

Set the voltage value of overvoltage protection.

**Example**

OVP:SETting CH1, 32

**18. OCP:SETting****Syntax**

OCP:SETting < channel >,< current value >  
< Channel > := { CH1 | CH2 }

**Functional Description**

Set the current value of overcurrent protection.

**Example**

OCP:SETting CH1, 3

**19. OVP:VALUE?****Syntax**

OVP:VALUE? < channel >  
< Channel > := { CH1 | CH2 }

**Functional Description**

Read the voltage value of overvoltage protection.

**Example**

OVP:VALUE? CH1

**20. OCP: VALUE?****Syntax**

OCP: VALUE? < channel >  
< Channel > := { CH1 | CH2 }

### Functional Description

Read the current value of overcurrent protection.

### Example

OCP: VALUE? CH1

## 21. Recall: STAT?

### Syntax

Recall: STAT?

### Functional Description

Read recalled data status settings

The query returns

0 represents not recall data status.

1 represents recall M1.

2 represents recall M2.

3 represents recall M3.

4 represents recall M4.

5 represents recall M5.

### Example

Recall: STAT? The query returns 1.

## 22. SYSTem: ERRor?

### Syntax

SYSTem: ERRor?

### Functional Description

Read the error code and information of power supply.

### Syntax

SYSTem:VERSion?

### Functional Description

Query the software version.

## 23. SYSTem:VERSion?

### Syntax

SYSTem:STATus?

### Functional Description

Return the working status of the instrument.

## 24. SYSTem: STATus?

### Example

SYSTem:STATus? The query returns 0x0224.

### Description

The return information is in hexadecimal notation. When the user confirms the status, it needs to convert to binary format. The hexadecimal values represent system status as follows:

| Bit Number | Status   |
|------------|--|
| 0          | 0: CH1 CV mode; 1: CH1 CC mode                             |
| 1          | 0: CH2 CV mode; 1: CH2 CC mode                             |
| 2,3        | 01: Independent mode; 10: Parallel mode<br>11: Serial mode |
| 4          | 0: Output off ; 1: enable                                  |
| 5          | 0: OVP off ; 1: enable OVP                                 |
| 6          | 0: OCP off ; 1:enable OCP                                  |