

LINI-T.



LM600/800/1000/ 1200/1500

Laser Rangefinder

**Operating Manual** 



No.6, Gong Ye Bei 1st Road, Songshan Lake National High-Tech Industrial Development Zone, Dongguan City, Guangdong Province, China Tel: (86-769) 8572 3888 http://www.unl-trend.com

P/N: 110401109446X

# UNI-T<sub>s</sub>

# UNI-T.

#### \land Warning

- Do not stare at the transmitting aperture when laser is transmitting.
- Staring at the sun through the device can cause permanent injury to eyes.
- Do not aim device directly into the sun in order to avoid causing a permanent damage to the inner components.
- Avoid the eye lens to the direct sunlight.
- Do not put the device beyond the extreme storage temperature (the storage temperature is -20 to 60℃)

#### Introduction

LM aser Rangefinder is a portable photoelectric device, which combines telescope with laser to measure angle and distance. The two main aspects are:

a. While objects are in the observable range, the distance of fixed or slow moving objects can be measured. LM series have advantages such as high accuracy, short measurement time, intuitive display, and electricity saving through auto power off.

b. The multifunctional rangefinder adopts the latest technology to measure target distance and angle. It can display target distance, relative height, horizontal distance, and the angle between device-to-target line and ground plane (elevation or depression angle).

 Laser emission power of the device is low and safe to the eyes. LM series are small, lightweight, and portable. These devices are powered with lithium battery, which are easy to recharge and with long working hours.

3. Laser Rangefinder can be applied to engineering

surveying and measurement, power line inspection, forestry prospect & design, constructions building, internet planning survey & design, communication repairing, navigation measuring, animal surveying and hunting etc.

#### Features

- Multifunctional LCD sighting telescope
- Silent operation and auto shut off
- Use pulse laser.
- Fast distance measurement (Note: Max distance will change with the reflectivity of different objects and the environment)

#### UNI-T

1. Laser Transmitting Objective Lens

- 2. Laser Receiving Objective Lens
- 3. Mode Switching Key

2

**Appearance** 

- 4. Power/Transmitting Key
- 5. Observing Eye Lens/LCD
- 6. Rotary Focusing
- 7. Micro USB Charging Port and indication light

UNIER

2

3

5 6

#### **Eye Lens LCD Symbols**



Eye Lens LCD Symbol

- 1. Distance measurement indicator
- 2. Measuring mode

3. Angle Data

- 4. Horizontal and height data
- 5.Target indicator
- 6. Horizontal and height measurement indicator
- 7. Distance Unit
- 8. Flag indicator

#### **Operation Introductions**

1. 2 keys on the device: the power/transmitting key and the MODE key. Press the power key for about 1s to turn on the device.

JNF

Short press MODE button to switch between 2 measurement modes.

 Multifunctional measurement modes (distance /height/angle/continuous measurement and flag locking function)

2) Speed measurement mode with SPD indicator

 Press the b key once and the distance will be measured once. When the distance is measured, a circle will be displayed in the center of LCD screen. After the measurement is finished, the direct distance data between the target and the telescope will be displayed on the top of screen while vertical height data or pitch angle data will be will be displayed in the bottom. If the target is unclear or beyond the specified range, — will be displayed.

# UNI-T.

#### The below is the measurement drawing





 Keep pressing the <sup>⊕</sup> key to measure continuously. The flag lock function is available in Golf mode. In common scanning mode, the distance data of target will constantly refresh on the display. Release the <sup>⊕</sup> key to stop distance-scanning measurement.

#### Speed Measurement

**Conditions:** a) The object is perpendicular to the object lens; b) The target is moving at a constant speed.

**Operations:** a) Short press MODE button to switch to speed mode, and "SPD' is displayed on LED; b) Short press (b) button, the bull's-eye will follow the measured object until result is obtained.

- 5. The device will auto shutoff after 10 seconds of inaction.
- 6. indicates the low battery. When is displayed, the battery should be changed.
- 7. Battery lifetime: The device can be operated for around 8000 times (at normal temperature). The target focus, measurement, auto power-off are all treated as one working cycle. The data may change according to other factors like the temperature, target shape, and color.
- 8. LM series use a 3.7V rechargeable lithium battery. Please disconnect the lithium battery charging cord

after it is fully charged to prolong battery lifetime.

 Diopter Adjustment: Adjust the diopter in order to obtain clear photos on the lens. Firstly, start the power, then rotate anticlockwise the eye lens until the screen comes into focus.

#### **Precautions**

1. LM Laser Rangefinder transmits infrared pulse laser which is invisible and harmless to eyes. The infrared pulse laser is then reflected back to the optics receiver from the target. By measuring the round trip time of the pulse laser from the finder to the target, the system adopts an accurate method to calculate the distance. The max range depends on the reflectivity, color, surface, finish, dimension, and real shape of the target.

The following criterias can obtain the bes measurements.

- Sunny day
- Target is bright
- Target surface is glossy
- · No impurity in air
- Target surface is of high-reflection

## UNI-T<sub>s</sub>

The below factors might affect measurement range and accuracy.

- Target is black
- It is snowy, rainy or foggy day
- Target surface is of diffused reflection
  - Target is tiny or micro
- Target need to be measured through the glass
- Target is dynamic
- 2. Li-ion battery: Operating Temperature(-10°C ~60°C); Rated capacity: 1500mAh; Dimension: 52.5\*42.5\*6.5mm; One Year Warranty
- 3. Do not touch the lens surface with fingers when you are operating in order to avoid destroying the lens coating.
- 4. As the laser rangefinder has been precisely calibrated, please do not dismantle it at random.
- When the exposed lens is not clean, please wipe it lightly with glass cloth. Do not wipe it with other things in order to avoid destroying the optics glass coating.

## UNI-T,

- 6. Avoid crashing or pressing the device when it is carried or used. Do not let the finder be baked or corroded.
- Avoid storing the device in damp environments. Please store in dry, cool and ventilated places. Prevent leaving it in direct sunlight. Avoid sudden change of temperature and dust.
- If the device is damaged, please send it to the approved technical site instead of disassembling it by yourself for repair.
- 9. Do not point the device directly to the sunlight or hard light.

#### **Specifications**

	Product Model	LM600	LM800	LM1000	LM1200	LM1500
	Distance Range	5 <del>-</del> 600yd	5 <b>-</b> 800yd	5 <b>-</b> 1000yd	5 <b>-</b> 1200yd	5 <b>-</b> 1500yd
	Velocity Range	0-300km/h				
•	Accuracy	±1yd±Range×0.2%				
	Magnification	6X				
	Lens Diameter	24mm				
	Measurement Height	250 yd	300yd	450 yd	500yd	600yd
	Measurement Angle	±45° ±1°				
	Angle Error					
Weight 212g						

Note: ±1yd accuracy is tested under optimal condition. Actual measurement might be different according to the target and environment. Measurement return time is between 1 to 4 seconds. Angle error is tested under optimal condition.

