# System Requirements

- Pentium 1 Gigahertz (GHz) processor or faster
- At least 1GB of RAM
- At least 2GB of available space on the hard disk
- USB 2.0/3.0

#### software only supports the following operating systems:

- Microsoft Windows Vista
- Microsoft Windows 7
- Microsoft Windows 8
- Microsoft Windows 10

If your Windows does not contain the corresponding service pack version, please perform a Windows update first.

## **Installing the Software**

- 1. Insert the installation CD-ROM into your computer
- 2. The menu will be opened automatically (if installation doesn't start immediately, double-click Setup.exe in your CD-ROM directory).

## Using the Software

### 1. Interface and basic functions

<u>F</u> ile <u>H</u> elp								
🖉 🔀 🕞 Connect Disconnect Start	Stop Export	() Options Manual	1					<mark>∏</mark> → Close
Ap	Table Table	🗠 Chart						
<b>2</b> 5 m/S2	No.	Date/Time	Function	Value	Unit	Frequency(Hz)		^
2.0	1	2019-07-24 14:25:38	Ар	0.2	m/S2	10-10kHz		
2	2	2019-07-24 14:25:38	Ap	0.2	m/S2	10-10kHz		
10-10kHz	3	2019-07-24 14:25:39	Ap	0.2	m/S2	10-10kHz	4	
♀ ₫ ✿ ⑪	4	2019-07-24 14:25:39	Ар	0.2	m/S2	10-10kHz		
<ul> <li>Store Data</li> <li>I.I Live Data</li> </ul>	5	2019-07-24 14:25:39	Ар	0.2	m/S2	10-10kHz		
Measure1	6	2019-07-24 14:25:39	Ap	0.2	m/S2	10-10kHz		
	7	2019-07-24 14:25:39	Ap	0.2	m/S2	10-10kHz		
3	8	2019-07-24 14:25:39	Ap	0.2	m/S2	10-10kHz		
	9	2019-07-24 14:25:39	Ap	0.2	m/S2	10-10kHz		
	10	2019-07-24 14:25:39	Ap	0.2	m/S2	10-10kHz		
	11	2019-07-24 14:25:39	Ap	0.2	m/S2	10-10kHz		
	12	2019-07-24 14:25:40	Ap	0.2	m/S2	10-10kHz		
	13	2019-07-24 14:25:40	Ap	0.2	m/S2	10-10kHz		
	14	2019-07-24 14:25:40	Ap	0.2	m/S2	10-10kHz		
								*

Area	Description
1	Menu and toolbar
2	Shows the live-data from the DMM
3	Data items,contain live-data and store-data
4	Data details, contain a table and a chart

### 2. Get live-data

Make sure the meter and computer are connected via a USB cable

- 1. Click the of and the software will attempt to connect to the meter
- 2. Click the b and the software will get data from the meter
- 3. Live-data will be displayed in area 2
- 4. Data details will be saved in the form of tables and charts.

### 3. Get Store-Data

1. The stored-data will be saved in the "Store Data" item.



1. Click the



2. Select the export project as needed. If you export to PDF, you can select a scene picture.

<ul> <li>Table(XLS)</li> <li>Chart(JPG)</li> </ul>		
	OK	Cancel

3. Input file name

#### 5. Setup software

•	Click 🙆 Options	to open options dialog
	Sample p	points 1000 🚔 🗹 Infinite
	Sample	e rate OmS ≑
	Skip repeat re	eading 🗌
		Ok Cancel

- "Sample Points": Set the number of sampling points. If "Infinite" is checked, the number is unlimited
- "Sample rate": Set the sampling rate. If the set rate is greater than the actual rate, the actual rate will prevail; if set to 0, the actual rate will be sampled
- "Skip repeat reading": If checked, the same sample value as the previous one is not recorded

#### 6. Item operation



Name	Description
Set to active	Set the selected item to be activated, and the received data will be saved to this item.
Rename	Rename the selected item
New	Create a new item and set it to active
Delete	Delete the selected item

•	Sto	re-data		
	0	<b>L</b>		1000
	_	÷		1000
		📟 Store Data 👝		
	~	ilit Live Data 💡	Set to active	ю
		🖤 Measure 🕎	Download	0
		🖙 Import1	c,	- 6UO

Name	Description
Set to active	Set the selected item to be activated
Download	Download store data

#### 7. Get help

Click ?? to open the "Software user manual"