

## System Prerequisites

### Recommended configuration


<b>Processor</b>	Pentium® 4 or higher with support of all customary operating systems
<b>Operating system</b>	Microsoft Windows® 2000 / XP / Vista / Win7
<b>Memory</b>	512 MB RAM or higher
<b>Monitor</b>	VGA (1024 x 768)
<b>Drive</b>	CD-ROM
<b>Input device</b>	Mouse or compatible
<b>Interface</b>	USB for data transmission

### Install Software

- Insert the provided CD disk into CD-ROM drive.
- Double-click “XXX\_VX.XX.exe” (X can be 0 to 9 or blank, indicating the software version)
- The pop-up windows will guide you through the program setup process.


UNI-TREND.VN

Main Screen





① Main display screen of measurement

② Secondary display screen for measurement

③  Blinking indicates meter is connected to the software

④ Measurement data in graph

Using Program

 Click "Connection"  and is blinking indicates meter is successfully connected to the PC and meter will automatically start taking measurements. Primary display screen shows measurement, secondary display screen shows all measurement data.


NO	Time	MMode	MValue	MUnit	SMode	SValue	SUnit	Freq
41	2011-11-11 11:02:21	Cp	1.7	pF	D	0.106		1KHz
42	2011-11-11 11:02:22	Cp	1.7	pF	D	0.106		1KHz
43	2011-11-11 11:02:22	Cp	1.7	pF	D	0.106		1KHz
44	2011-11-11 11:02:23	Cp	1.7	pF	D	0.106		1KHz
45	2011-11-11 11:02:23	Cp	1.7	pF	D	0.106		1KHz
46	2011-11-11 11:02:24	Cp	1.7	pF	D	0.106		1KHz
47	2011-11-11 11:02:24	Cp	1.7	pF	D	0.106		1KHz
48	2011-11-11 11:02:25	Cp	1.7	pF	D	0.106		1KHz
49	2011-11-11 11:02:25	Cp	1.7	pF	D	0.106		1KHz
50	2011-11-11 11:02:26	Cp	1.7	pF	D	0.106		1KHz
51	2011-11-11 11:02:26	Cp	1.7	pF	D	0.106		1KHz
52	2011-11-11 11:02:27	Cp	1.7	pF	D	0.106		1KHz
53	2011-11-11 11:02:27	Cp	1.7	pF	D	0.106		1KHz
54	2011-11-11 11:02:28	Cp	1.7	pF	D	0.106		1KHz
55	2011-11-11 11:02:28	Cp	1.7	pF	D	0.106		1KHz

- ① Zoom
- ② Print data
- ③ Save data (\*.txt, \*.xls, \*.xml)
- ④ Open files (\*.txt, \*.xls, \*.xml)
- ⑤ Deleting current data and create a new data.

**Repeat:** Tick to display every measurement with the interval you set. Un-tick "Repeat", the secondary display screen will only show measurement result that is different from the last measured temperature. The graph display will show complete measurement result in graphics despite "Repeat" is ticked or un-ticked.

**Sampling Interval** allows you to set the sampling intervals of measurement ( 1 to 9999 seconds).

**Note:** when measurement data reaching to 10000 sets (measurement No.), a warning message will pop up and stop measurements. Save or clear the measurement data before continuing next measurements.



- ① Zoom graphic
- ② Save graph in current page as \*.bmp
- ③ Deleting current data and create a new data.
- ④ Last page
- ⑤ Next page
- ⑥ Current page
- ⑦ Previous page
- ⑧ First page
- ⑨ Set numbers of measurement data on graph display